

# Proper Sizing for Insulating Rubber Gloves

---



Measure the circumference of the palm, as shown above and add 1" to the measurement to determine the glove size needed.

Example:

- A measurement of 9" plus the 1" would be 10" and would require a size 10 glove.

Glove Sizes Available: 8, 9, 10, 11 and 12

Please call us at Cementex Products, Inc. if you have any questions or would like to check stock.

***Cementex***

**The Safety Tool Specialists**